

1. WINDOW PREPARATION

Install only in a solid, non-rotting window track
Expand guard to fit tightly into outside window
track.

2. TO INSTALL WINDOW GUARD

Temporarily support guard in a level position NO
MORE THAN 4 1/2" inches from window sill to upper
half of bottom bar. Mark Location of top holes on
each side. Remove Guard and drill 5/32" dia. pilot holes
1" deep.

3.) Reposition guard and drive #10 x 1" lg. tamper
proof screws (provided by manufacture) part way into
jamb. Drill remaining holes and install all screws fully
into window jamb

