

1. WINDOW PREPARATION

Install only in a solid, non-rotting window track
Expand guard to fit tightly into outside window track.

2. TO INSTALL WINDOW GUARD

Temporarily support guard in a level position. Mark Location of holes on upper and lower part of the window frame. Remove Guard and drill $\frac{5}{32}$ " dia. pilot holes 1" deep.

3.) Reposition guard and drive #10 x 1" lg. tamper proof screws (provided by manufacture) part way into jamb. Drill remaining holes and install all screws fully into window jamb

